

E12S20L ASSEMBLY INSTRUCTIONS

- STEP 1: PLACE FRONT BARREL ASSEMBLY AND HANDLE ASSEMBLY
ONTO A FLAT SURFACE.
- STEP 2: PULL ROD OUT OF THE BARREL UNTIL FLATS ON ROD ARE
ACCESSIBLE. USING A 7/16" WRENCH, ASSEMBLY FRONT
BARREL ASSEMBLY ROD TO HANDLE ASSEMBLY RACK.
- STEP 3: ATTACH COUPLING TO HANDLE ASSEMBLY.

